Important Facts about your Home Phone Connect

Dialing

- Your Verizon Wireless Home Phone Connect requires 10-digit dialing. Please dial the three digit Area Code when calling local and long distance numbers.
- Your Verizon Wireless Home Phone Connect does not support rotary or pulse dialing phones.

Call Forwarding

Verizon Wireless Home Phone Connect allows customers to forward calls to another phone number, including your mobile phone or office number. Your home phone will not ring until you deactivate the service. Airtime applies to forwarded calls even if you send the call to wireline telephones. When forwarding calls to phone numbers outside your local calling area, you will be billed for any toll, long distance and airtime charges incurred. Additional per-minute charges may apply to all forwarded calls. This feature is also known as "Immediate Call Forwarding".

To Activate Call Forwarding:

1. Dial *72.
2. Immediately enter the phone number where you want calls to be forwarded (e.g. *72-212-123-4567).
3. You will hear a confirmation tone.
4. Hang up your home phone or return the phone receiver to its base.

To Deactivate Call Forwarding:

1. Dial *73.
2. You will hear a confirmation tone.
3. Hang up your home phone or return the phone receiver to its base.

Fax Machine Compatibility

- Your Verizon Wireless Home Phone Connect does not support incoming or outgoing fax service.